Linkstyle

# Smart Nursery Lamp
# User Guide

If you need any support, don't hesitate to reach out to us at:

contact@linkstyle.life
1-888-419-4888

# Important Safety Information

This is an electric lamp - NOT a toy!
To avoid risk of fire, burns, personal injury, and electric shock, it should not be played with or placed in reach of small children.

To ensure correct and safe installation, usage, and functioning of the product, always follow these instructions carefully and keep for future reference.

Use ONLY the provided USB-C cable and AC power adapter. For enough brightness, ensure and input power of more than 5V 1.5A.

The luminaire cannot be replaced, please do not dismantle or modify the lamp by yourself. Otherwise, it will be deemed as a waiver of warranty.


DO NOT place or operate this device near sources of extreme heat, moisture, or corrosive substances.

DO NOT operate with a damaged cord or after malfunction occurs, or damage it in any manner.

DO NOT remove the power plug with wet hands, as it may cause electrical shock.

Always unplug the light before performing installation, maintenance, or repair activities.

Follow local regulations regarding disposal or recycling of the device and components.


Night Light Control
Auto OFF Timer
Sound Control
M
30'
60'
120'
240'
WiFi Reset
Wi-Fi On/Off/ Pairing
USB-C Input Port


# Button Controls





Press to cycle through 3 sound modes:
Nature -> Animal -> Sleep




Press to cycle through sounds in each mode:
10 Nature sounds, 7 Animal sounds, 8 Sleep sounds.




Press to play or pause.




Press to increase or decrease volume by 1 level (out of a total of 16 levels).
Press and hold increase and decrease volume steplessly.




Press to turn night light on and off
Press and hold to adjust brightness




Press to cycle through auto timer intervals:
30min -> 60min -> 120min -> 240min -> Off
Press and hold to cancel auto-off timer




Press to turn Wi-Fi on and off
Once turned on, press and hold until the LED indicator flashes blue to enter pairing mode:

- Flashing blue -- Pairing
- Solid blue -- Connected
- Solid red -- Connection failed/Offline

# Smart Functions


## Install the Linkstyle app

Scan the QR code below to download and install the Linkstyle app. Register a new account on the app if you do not have one.

*Alternatively, you can also search for “Linkstyle” on the Apple App Store or Google Play Store to find the app.

*****Important Note:**


When registering an account in the Linkstyle app, be sure to set the region to United States of America.



# Add Lamp to App

1. An unpaired lamp should enter Pairing mode automatically when first plugged in. If it does not, turn on the Wi-Fi on the lamp by pressing the Wi-Fi button, then press and hold the Wi-Fi button until the LED indicator flashes blue.
2. From the "Devices" page of the Linkstyle app, tap the "Add" button to add a new device.
3. Tap the Lighting tab, then tap Light Source (Wi-Fi).
4. Follow the on-screen instructions to finish adding the lamp to the app.

# Notes & Specifications




## Cleaning & Maintenance:

Wipe with a dry cloth to clean and get rid of dust on a regular basis.

DO NOT immerse in water or other liquids.
AVOID contact with sharp objects and strong chemicals.
DO NOT drop or crush this device.
Store in a cool, dry place when not in use.

Product Specifications

**Power Input:** 100-240V ~50/60Hz, DC 5V 1.5A
**Power Output:** Light - 3.8W, Speaker - 3W
**Supported Wi-Fi Protocol:** IEEE 802.11 b/g/n 2.4GHz
**Supported OS:** Android 5.0 or higher, iOS 9.0 or higher
**Max Brightness:** 125lm +/- 10%
**White Color Temperature:** 2700K
**CRI:** ≥80
**Operating Temperature:** -10ºC to 40ºC
**Working Lifetime:** 25000 hours

## FCC Compliance

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experience radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Apple and Apple logos are trademarks of Apple, Inc., registered in the U.S. and other countries. App Store is a service mark of Apple, Inc.
Amazon, Alexa, and all related logos are trademarks of Amazon.com Inc. or its affiliates.
Google and Google Play are trademarks of Google LLC.
Other third-party brands and names are the property of their respective owners.

# Linkstyle.life

Unlocking the enchanted life!