Linkstyle

Pet Water Fountain
User Guide

If you need any support, don't hesitate to reach out to us at:

contact@linkstyle.life
1-888-419-4888

Safety Notice

Warning:

Failure to follow these safety notices could result in fire, electric shock, or other injuries. Read all the safety notices below before use.

- Avoid high humidity or extreme temperatures
- Avoid long exposure to direct sunlight or strong ultraviolet light
- Do not drop or expose the unit to intense vibration
- Do not disassemble or try to repair the unit yourself
- Do not expose the unit or its accessories to flammable liquids, gases, or other explosives
- Ensure that the water level in the water tank is between the minimum and maximum level lines
- Replace the filter once a month to maintain adequate filtration
- If the pump generates excess noise after a period of use, remove the pump and clean it

Package Includes

1 x Pet Water Fountain

1 x Cotton Filter


1 x USB Power Cable

LED Indicator





Blue Light On: Device status normal



Flashing Red Light: Water level too low

Red Light On: Operation stopped


Spout
Head Cover
Filter
Top Cover
Pipe
Pump
Water Tank

Assembling the Fountain

1  Connect one end of the pipe to the pump	2  Connect the other end of the pipe to the lower end of the top cover
3  Route the USB cable through the built-in cable channel in the water tank	4  Make sure the water level is between the minimum and maximum level lines

5  Install the top cover onto the water tank	6  Wet the filter and place it into the slot in the top cover
7  Tighten the head cover by turning it clockwise	8  Install the spout and turn on the power switch

Technical Specifications

Water Capacity: 1.4L

Power supply: DC 5V 1A USB Cable

Material: ABS Plastic

Dimension: 6.41 in x 6.46 in x 6.30 in (163mm x 164mm x 160mm)

Net Weight: 17.6 oz (0.5kg)

Apple and Apple logos are trademarks of Apple, Inc., registered in the U.S. and other countries. App Store is a service mark of Apple, Inc.
Amazon, Alexa, and all related logos are trademarks of Amazon.com Inc. or its affiliates.
Google and Google Play are trademarks of Google LLC.
Other third-party brands and names are the property of their respective owners.

Linkstyle.life

Unlocking the enchanted life!